



# V2C CLOUD OCPP CONFIGURATION GUIDE


① After creating an account on V2C Cloud, and pairing the e-charger, you need to access the OCPP page by pressing on the OCPP button on the left side.



② In the OCPP page, we will only see the chargers that have internet access since OCPP can only be used with chargers that are connected to the internet.



③ By clicking on the green pencil, we can configure the URL of the central station.



④ And finally, we activate OCPP by clicking on the OCPP box.

